

**INDUKTIVE RINGSENSOREN
KREUZSCHEMA MONTAGEABSTÄNDE**

Abstand vom Ring zu Metall (z.B. Montagewinkel)		Montage nebeneinander	Montage übereinander	
IR... 06 PSK-ST4	3 mm	0 mm	5 mm	
IR... 10 PSK-ST4	3 mm	0 mm	5 mm	
IR... 15 PSK-ST4	3 mm	0 mm	5 mm	
IR... 20 PSK-ST4	3 mm	0 mm	10 mm	
IR... 25 PSK-ST4	3 mm	10 mm	10 mm	
IR... 35 PSK-ST4	5 mm	10 mm	30 mm	
IR... 50 PSK-ST4	10 mm	10 mm	30 mm	
IR... 80 PSK-ST4	20 mm	10 mm	50 mm	(bei Sens. max.)
IR... 100 PSK-ST4	20 mm	10 mm	50 mm	(bei Sens. max.)
IR... 130 PSK-ST4	20 mm	25 mm	100 mm	(bei Sens. max.)
IR... 150 PSK-ST4	20 mm	25 mm	100 mm	(bei Sens. max.)
IRDB 04 PSK-ST4	3 mm	0 mm	5 mm	(bei Sens. max.)
IRDB 06 PSK-ST4	3 mm	0 mm	5 mm	(bei Sens. max.)

Abstand vom Ring zu Metall (z.B. Montagewinkel)		Montage nebeneinander	Montage übereinander	
IRS 06 PSK-ST3	3 mm	0 mm	5 mm	
IRS 10 PSK-ST3	3 mm	0 mm	5 mm	
IRS 15 PSK-ST3	3 mm	0 mm	5 mm	
IRS 20 PSK-ST3	3 mm	0 mm	10 mm	
IRS 25 PSK-ST3	3 mm	0 mm	10 mm	
IRS 50 PSK-ST4	10 mm	0 mm	30 mm	

Abstand vom Ring zu Metall (z.B. Montagewinkel)		Montage nebeneinander	Montage übereinander	
SIA 05...	n/a	10 mm	25 mm	(bei Sens. max.)
SIA 12...	n/a	10 mm	30 mm	(bei Sens. max.)
SIA 15...	n/a	10 mm	30 mm	(bei Sens. max.)
SIA 22...	n/a	20 mm	60 mm	(bei Sens. max.)
SIA 30...	n/a	20 mm	60 mm	(bei Sens. max.)
SIA 44...	n/a	250 mm	300 mm	(bei Sens. max.)
SIA 63...	n/a	250 mm	300 mm	(bei Sens. max.)
SIA 100...	n/a	650 mm	600 mm	(bei Sens. max.)